E29 Pull Bar Assembly Instructions For E1L & E1E Stair Climbers

ltem	Description	Qty.	Part No.
А	Pull Bar	1	2002-190

Tools Required:

- (2) 1/2" wrench/socket
- (1) Needle nose pliers
- 1. To add a pull bar to your hand truck with stair climbers first remove the wheels and stair climbers, setting aside all hardware.
- 2. Take the pull bar (A) and insert it between the stair climbers as shown.
- 3. Holding the assembly together reattach the stair climbers to the hand truck, then reattach the wheels.



www.magcoa.com (800) 255-9390 Pull bar hole